


Možnosti nastavení



VZDÁLENOST MISKY OD HRANY (D)

	3	4	5
3	8	9	10
4	7	8	9
5	6	7	8
6	5	6	7
7	4	5	6
8	3	4	5
9	2	3	4
10	1	2	3

TLOUŠŤKA PODLOŽKY (H)

$H = 8 + D - S$

Doporučený počet závěsů

